


Approved Residential Connection Pipe Locations

The gas connection must be located at the front of the property, or no more than 3m down the side.



FRONT BOUNDARY

..... ACCEPTABLE CONNECTION POSITIONS ⊗ UNACCEPTABLE CONNECTION POSITIONS - - - - GAS MAIN

REQUIRED CLEARANCES

